



## Technical Guide: AXIS

### **Release Adjustments:**

The AXIS has three points of adjustment for trigger tension, trigger travel, and length from release to strap.

### **Trigger Travel:**

You will need a 5/64 allen key. Trigger travel is adjusted using the trigger travel adjustment pin. Turning it clockwise decreases trigger travel while turning counterclockwise increases trigger travel.

### **Trigger Tension:**

You will need a 5/64 allen key. Trigger tension is adjusted using the screw located on the outside of the index finger hook. Turning the tension adjustment screw clockwise makes the trigger feel heavier to activate, turning it counterclockwise makes it feel lighter. Adjust the screw until you find your desired tension.

### **Lengthening the release from the wrist strap:**

To lengthen the release from the wrist strap you will loosen the two screws located in the strap clamp. When you find the correct length for your hand, retighten the screws in the strap clamp making sure that it is secure and will not slip or move.

### **Resetting the release:**

To reset the release simply pull the thumb trigger fully back and the release will reset due to the return spring in the hook and internal springs.

### **Some release safety and care tips:**

Always draw your bow pointed at a target and NEVER without an arrow on the string. A case of an accidental release could dry fire your bow and damage your equipment. After any release adjustments test the release before drawing your bow Always inspect your release and D loop before shooting. Keep your release dry and free of debris.

**NEVER DISSASSEMBLE YOUR RELEASE**

**NEVER LUBRICATE YOUR RELEASE**

**Unintentional Activation or letting go of the release at any point of draw can cause serious damage or death to yourself, others, and equipment. This is not covered under our warranty.**

**Warranty Services:**

If anything were to happen with your release that you would have to send it in for repairs, please contact our customer service and we will assign an RMA number for you to return your release. Our customer service line is 315-258-9269 or fill out the RMA form on our website. We hope you enjoy your release and would love to hear your feedback. Our greatest source of improvement is you. We appreciate your business and value your thoughts. Contact us on our website or through [Info@stanoutdoors.com](mailto:Info@stanoutdoors.com).